


# Quick Start Guide



## TIMEX T121 Alarm Clock

### Setting the Time

While holding *TIME* (1), press *HOUR* (2) to cycle.




While holding *TIME* (1), press *MIN* (3) to cycle.




Red dot at *PM* = p.m.  
No red dot at *PM* = a.m.

### Setting the Alarm


While holding *ALM\_SET/RESET* (1), press *HOUR* (2) to cycle.





While holding *ALM\_SET/RESET* (1), press *MIN* (3) to cycle.



Release *ALM\_SET/RESET* (1).




Press *ALM ON/OFF* (4).



Red dot at *ALM* = ON  
No red dot at *ALM* = OFF


## Resetting the Alarm

Press *ALM\_SET/RESET* (1). (Turns alarm off, then on again.)





## Snoozing the Alarm

Press *SNOOZE* (1). (Snoozes alarm for 10 minutes.)



## Turning ON/OFF the Alarm

Press *ALM ON/OFF* (1).




Red dot at *ALM* = ON  
No red dot at *ALM* = OFF

## Installing Backup Batteries (optional)

Batteries sold separately. For backup purposes only.

Remove *battery door* (1) from bottom of clock.



Install two AAA batteries, and replace battery door.

